

Model **E5CS-U/E5CSV**
Temperature Controller

English INSTRUCTION MANUAL

Thank you for purchasing the OMRON E5CS-U/E5CSV Digital Temperature Controller. This manual describes the functions, performance, and application methods needed for optimum use of the product.

- Please observe the following items when using the product.
- This product is designed for use by qualified personnel with a knowledge of electrical systems.
 - Before using the product, thoroughly read and understand this manual to ensure correct use.
 - Keep this manual in a safe location so that it is available for reference whenever required.

OMRON Corporation
©All Rights Reserved

Safety Precautions

Key to Warning Symbols

CAUTION Indicates a potentially hazardous situation which, if not avoided, is likely to result in minor or moderate injury or property damage. Read this manual carefully before using the product.

CS1

1651882-9B

Mounting

Dimensions

E5CS-U (mm): 94.45 (width), 48 (height), 7.75 (depth), 6.25 (depth), 72.5 (width), 14.2 (width), 44.8 (height), 58 (height)

E5CSV (mm): 84 (width), 48 (height), 1.5 (depth), 78 (width), 44.8 (height), 58 (height)

In the pack:
 • Main unit
 • Adapter
 • Instruction Manual
 • °C/°F labels, specifications entry label *1
 • Watertight packing *2

*1 Enter the settings on the specifications entry label and use it to manage the settings. (E5CS-U only)
 *2 E5CSV only

• The main unit can be removed for maintenance without disconnecting the terminal wiring. (E5CSV only)
 • Do not remove the terminal block. Doing so may result in failure or malfunction. (E5CSV only)

Installation Diagrams

Flush mounting (Panel cutout)

Individual mounting (mm): 45 ±0.0 (width), 45 ±0.0 (height), 60mm (depth)

Side-by-side mounting (waterproof not possible) (mm): 48 x number of units - 2.5 (width), 45 ±0.0 (height)

When waterproofing is required, be sure to mount the controller separately. Attach the waterproof packing from the terminal side and then insert the controller to the panel.
 • Recommended panel thickness is 1 to 4 mm.

Insert the controller through the hole in the panel. Push the adapter on from the rear and fasten temporarily, removing any gap between the controller, panel and adapter. Finally, secure two fixing screws alternately keeping the torque to between 0.29 to 0.39 N·m. Refer to the dimension diagram for the mounting status.
 • When mounting more than one Temperature Controller, be sure that the heat generated by the Temperature Controllers does not cause the ambient temperature to exceed the specified value.
 • Close side-by-side mounting is possible in one direction only, either horizontally or vertically.

Surface mounting

When mounting plural units in vertical arrangement, leave space of approx. 20 mm above and below the mounting socket.

Labels: Duct and etc., Hook, P2CF-□, Panel

Terminal Layout

E5CS-R□, -Q□ (No alarm output type)
Suitable socket is P2CF-08-□ or P3G-08

E5CSV-R□, -Q□ (No alarm output type)

E5CS-R1□, -R2□, -Q1□, -Q2□ (Alarm output type)
Suitable socket is P2CF-11-□ or P3GA-11

E5CSV-R1□, -R2□, -Q1□, -Q2□ (Alarm output type)

Control output: Voltage output 12V DC 21mA, Relay output 1c 250V AC 3A (resistive load)

Do not use: ①, ②, ③, ④, ⑤, ⑥, ⑦, ⑧, ⑨, ⑩, ⑪, ⑫, ⑬, ⑭, ⑮, ⑯, ⑰, ⑱, ⑲, ⑳

Input power supply: 100 to 240 V AC type, 24 V AC/DC type (no polarity)

Thermistor, Thermocouple, Platinum resistance thermometer

Names of Front Parts

Display

E5CS-U: LED deviation indicators, Temperature indicator, Output operation indicator, Alarm output operation indicator, Mode indicators, SP, ALM, ALM 1, 2, Up key, Mode key, Front door open/close notch, Down key, Front door

E5CSV: Tool hole, LED deviation indicators, Temperature indicator, Output operation indicator, Alarm output operation indicator, Mode indicators, SP, ALM, ALM 1, 2, Up key, Mode key, Hidden Protection key *1, Down key, Tool hole

Switch

E5CS-U: Protection switch, INIT switch *2, Control mode selector switch, Alarm mode selector switch *1

E5CSV: Alarm mode selector switch *1, Temperature range selector switch, Control mode selector switch, INIT switch *2, Protection switch

*1 There is no alarm mode selector switch on models without an alarm.
 *2 The INIT switch is always OFF.

Operation

Setting

Step1 Set the operating specifications with the switches.

Control mode selector switch

Switch	Function	OFF	ON
1	PID ON/OFF	ON/OFF control	2-PID control
2	Control period	20 seconds	2 seconds
3	Forward/reverse operation	Reverse	Normal
4	Input shift	Disable	Enable
5	Thermometer replacement	Thermocouple: K, J Platinum resistance thermometer: Pt100 Multi-input: Thermocouple	Thermocouple: K, L Platinum resistance thermometer: Pt100 Multi-input: Platinum resistance thermometer
6	Selection	°C	°F

Alarm mode selector switch

SW No.	Alarm type	Alarm output
0,9	No alarm function	Output off
1	Deviation upper/lower limit	ON: X, OFF: X
2	Deviation upper limit	ON: X, OFF: X
3	Deviation lower limit	ON: X, OFF: X
4	Deviation upper/lower range	ON: X, OFF: X
5	Deviation upper limit standby sequence ON	ON: X, OFF: X
6	Deviation lower limit standby sequence ON	ON: X, OFF: X
7	Deviation lower limit standby sequence ON	ON: X, OFF: X
8	Absolute value upper limit	ON: X, OFF: X

Step2 Set the control temperature.

Temperature indication

POWER ON

Present temperature *1

Set temperature SP indicator lit.

Alarm value 1 *2 ALM indicator lit.

Alarm value 2 *2 ALM indicator flashes.

Input shift value *3

*1 To start AT (auto-tuning), press and hold the Up and Down keys simultaneously for at least 2 seconds while the temperature is displayed on the temperature indicator. Perform the same operation to stop AT.
 *2 Displayed only for models with alarms.
 *3 Input shift value is not displayed when pin 4 of control mode selector switch is set to OFF.

Precautions for Safe Use

- Be sure to observe the following precautions to prevent operation failure, malfunction, or adverse effects on the performance and functions of the product. Not doing so may occasionally result in unexpected events.
- The product is designed for indoor use only. Do not use the product outdoors or in any of the following locations.
 - Places directly subject to heat radiated from heating equipment.
 - Places subject to splashing liquid or oil atmosphere.
 - Places subject to direct sunlight.
 - Places subject to dust or corrosive gas (in particular, sulfide gas and ammonia gas).
 - Places subject to intense temperature change.
 - Places subject to icing and condensation.
 - Places subject to vibration and large shocks.
 - Use/store within the rated temperature and humidity ranges. Provide forced-cooling if required.
 - To allow heat to escape, do not block the area around the product. Do not block the ventilation holes on the product.
 - Use specified size (M3.5, width 7.2 mm or less) crimped terminals for wiring. To connect bare wires to the terminal block, use copper braided or solid wires with a gauge of AWG24 to AWG18 (equal to a cross-sectional area of 0.205 to 0.832 mm²). (The stripping length is 5 to 6 mm.). Up to two wires of same size and type, or two crimped terminals can be inserted into a single terminal.
 - Be sure to wire properly with correct polarity of terminals. Do not wire any of the I/O terminals incorrectly.
 - Do not wire the terminals which are not used.
 - The voltage output (control output) is not electrically isolated from the internal circuits. When using a grounded temperature sensor, do not connect any of the control output terminals to ground. Otherwise unwanted current paths will cause measurement errors.
 - Allow as much space as possible between the controller and devices that generate a powerful high-frequency or surge. Separate the high-voltage or large-current power lines from other lines, and avoid parallel or common wiring with the power lines when you are wiring to the terminals.
 - Use this product within the rated load and power supply.
 - Use a switch, relay, or other contact so that the power supply voltage reaches the rated voltage within 2 seconds. If the applied voltage is increased gradually, the power supply may not be reset or malfunctions may occur.
 - When using PID operation (self-tuning), turn ON the power supply to the load at the same time or before turning the power supply to the Temperature Controller ON.
 - Design system (control panel, etc) considering the 2 second of delay that the controller's output to be set after power ON.
 - A switch or circuit breaker should be provided close to this unit. The switch or circuit breaker should be within easy reach of the operator, and must be marked as a disconnecting means for this unit.
 - Approximately 30 minutes is required for the correct temperature to be displayed after turning the power supply to the Temperature Controller ON. Turn the power supply ON at least 30 minutes prior to starting control operations.
 - Be sure that the platinum resistance thermometer type and the input type set on the Temperature Controller are the same.
 - When extending the thermocouple lead wires, always use compensating conductors suitable for the type of thermocouple. Do not extend the lead wires on a platinum resistance thermometer. Use only low-resistance wire (5 Ω max. per line) for lead wires and make sure that the resistance is the same for all three wires.
 - When drawing out the controller from the case, do not apply force that would deform or alter the Product.
 - When drawing out the controller from the case to replace the Product, check the status of the terminals. If necessary, replace the rear case as well.
 - When drawing out the controller from the case, turn the power supply OFF first, and: Absolutely do not touch the terminals or electronic components or apply shock to them. When inserting the controller, do not allow the electronic components to come into contact with the case.
 - Static electricity can damage internal components. Always touch grounded metal to discharge any static electricity before handling the Temperature Controller. When drawing out the controller from the case, do not touch the electronic components or patterns on the board with your hand. Hold the Temperature Controller by the edge of the front panel when handling it.
 - Do not use paint thinner or similar chemical to clean with. Use standard grade alcohol.
 - Use tools when separating parts for disposal.

SELF-DIAGNOSTIC FUNCTION

If an error occurs, it will be displayed on the temperature display. Check the type of error and correct the error accordingly.

Display	Error	Meaning	Action	Control output Reverse	Control output Normal
FFF	Overflow *1, *2	• The temperature has risen beyond the set temperature range. • With Thermistor types, the sensor is shorted.		OFF	ON
---	Underflow *1, *2	• The temperature has fallen below the set temperature range. • With Thermistor types, the sensor is disconnected.		ON	OFF
FFF (flashing)	TC/Pt multi-input models: A temperature sensor error has occurred at a temperature higher than the set temperature range.	• The temperature has risen beyond the overflow temperature. • The thermocouple or platinum resistance thermometer has failed.	Check the wiring of inputs, disconnections, shorts and input type.	OFF	OFF
---	Sensor error *1, *3	• The temperature has fallen below the underflow temperature. • The polarity (positive and negative) of thermocouple has been reversed. • The platinum resistance thermometer has failed.		OFF	OFF
E!! (flashing)	Memory error	• TC/Pt multi-input models: A temperature sensor error has occurred at a temperature lower than the set temperature range. • Memory has failed.	After the correction of input error, turn the power OFF then back ON again.	OFF	OFF

If the input value exceeds the display limit (-99 to 999), though it is within the control range, [ccc] will be displayed under -99 and [ddd] above 999. Under these conditions, control output and alarm output will operate normally.

*1 Alarm output (Models with alarm output type only)
 • The alarm output will operate as an abnormally high temperature alarm output when FFF is displayed (flashes).
 • The alarm output will operate as an abnormally low temperature alarm output when --- is displayed (flashes).
 • The alarm output will turn OFF when E!! is displayed.

*2 Errors are displayed only when the present temperature is being displayed.
 Errors will not be displayed if the set temperature, alarm set temperature, or input shift value is displayed.
 Overflow and underflow are not applicable to TC/Pt multi-input models.

*3 Sensor error detection function is not provided for thermistor type.

Conformance to EN/IEC Standards

This is a class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.

Conformance to Safety Standards

Reinforced insulation is provided between input power supply, relay outputs, and between other terminals.

Specifications

Power supply voltage	100 to 240V AC type 50/60Hz 24V AC type 50/60Hz / 24V DC type
Operating voltage range	85 to 110% of the rated voltage
Power consumption	Approx. 5VA (100 to 240V AC) Approx. 3VA (24V AC) / Approx. 2W (24V DC)
Indication accuracy (Ambient temperature: 23°C)	Thermocouple type E5CS-U: (±1.0% of indication value or ±0.2°C, which is greater) ±1 digit max. E5CSV: (±0.5% of indication value or ±1°C, which is greater) ±1 digit max. Platinum resistance thermometer type (±0.5% of indication value or ±1°C, which is greater) ±1 digit max. Thermistor type E5CS-U: 0.1%FS ±1 digit max. E5CSV: 0.5%FS ±1 digit max.
Control output	Relay output: 250V AC 3A (resistive load) Voltage output: 12V DC 21mA Electrical life of relay: 100,000 operations ON/OFF or 2-PID control Relay output: 250V AC 1A (resistive load) Electrical life of relay: 100,000 operations
Control method	ON/OFF or 2-PID control
Alarm output	Relay output: 250V AC 1A (resistive load) Electrical life of relay: 100,000 operations
Ambient temperature	-10 to 55°C (Avoid freezing or condensation)
Ambient humidity	RH 25 to 85%
Storage temperature	-25 to 55°C (Avoid freezing or condensation)
Altitude	Max 2,000m
Recommended fuse	T2A 250V AC, time-lag, low-breaking capacity
Weight	E5CS-U: Approx. 110g (main unit only) E5CSV: Approx. 120g (main unit only)
Degree of protection	E5CS-U Front panel: IP50, Enclosure Category 2 (as per IEC60529), Rear case: IP20, Terminal section: IP00 E5CSV Front panel: IP66, Rear case: IP20, Terminal section: IP00
Installation environment	Installation category II, pollution degree 2 (as per IEC61010-1)
Memory protection	EEPROM (non-volatile memory) (Number of write operations: 1,000,000)
Terminal	E5CS-U: Field wiring terminal (with P2CF-08 or P2CF-11) E5CSV: Field wiring terminal
Applicable Connection Sockets (Order Separately) (E5CS-U Only)	Sockets for no Alarm (8-pin): P2CF-08, P2CF-08-E, and P3G-08 Sockets for Alarm (11-pin): P2CF-11, P2CF-11-E, and P3GA-11

Suitability for Use

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the products in the customer's application or use of the product. Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product. NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product catalog for Warranty and Limitation of Liability.

OMRON EUROPE B.V.
Wegalaan 67-69, NL-2132 JD Hoofddorp The Netherlands
Phone 31-2356-81-300
FAX 31-2356-81-388
OMRON ELECTRONICS LLC
One Commerce Drive Schaumburg, IL 60173-5302 U.S.A.
Phone 1-847-843-7900
FAX: 1-847-843-7787
OMRON ASIA-PACIFIC PTE. LTD.
No. 438A Alexandra Road #05/08 (Lobby 2),
Alexandra Technopark, Singapore 119967
Phone 65-6835-3011
FAX 65-6835-2711

