

E5CS-U OMRON Temperature Controller

English Instruction Manual

Thank you for purchasing the OMRON E5CS-U Temperature Controller. This manual describes the functions, performance, and application methods needed for optimum use of the product.

- This product is designed for use by qualified personnel with a knowledge of electrical systems.
- Before using the product, thoroughly read and understand this manual to ensure correct use.
- Keep this manual in a safe location so that it is available for reference whenever required.

OMRON Corporation
© All Rights Reserved

Warning Symbols

CAUTION

Do not touch the terminals while power is being supplied. Doing so may occasionally result in minor injury due to electric shock.

Do not allow pieces of metal, wire clippings, or fine metallic shavings or filings from installation to enter the product. Doing so may occasionally result in electric shock, fire, or malfunction.

Do not use the product where subject to flammable or explosive gas. Otherwise, minor injury from explosion may occasionally occur.

Never disassemble, modify, or repair the product or touch any of the internal parts. Minor electric shock, fire, or malfunction may occasionally occur.

CAUTION - Risk of Fire and Electric Shock

a) This product is UL listed as Open Type Process Control Equipment. It must be mounted in an enclosure that does not allow fire to escape externally.

b) More than one disconnect switch may be required to de-energize the equipment before servicing.

c) Signal inputs are SELV, limited energy.

d) Caution: To reduce the risk of fire or electric shock, do not interconnect the outputs of different Class 2 circuits.

If the output relays are used past their life expectancy, contact fusing or burning may occasionally occur. Always consider the output relays are used past their rated load and electrical life expectancy. The life expectancy of output relays varies considerably with the output load and switching conditions.

Tighten the terminal screws to 0.50 N·m. Loose screws may occasionally result in fire.

Unexpected operation may result in equipment damage or accidents if the settings are not appropriate for the controlled system. Set the Temperature Controller as follows:

- Set the parameters of the Temperature Controller so that they are appropriate for the controlled system.
- Turn the power supply to the Temperature Controller OFF before changing any switch setting.
- Switch settings are read only when the power supply is turned ON.
- Make sure that the INIT switch in the control mode selector switches is turned OFF before operating the Temperature Controller.

A malfunction in the Digital Controller may occasionally make control operations impossible or prevent alarm outputs, resulting in property damage. To maintain safety in the event of malfunction of the Temperature Controller, take appropriate safety measures, such as installing a monitoring device on a separate line.

Suitability for Use

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the product in the customer's application or use of the product. Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product. NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also product catalog for Warranty and Limitation of Liability.

Precautions for Safe Use

- Be sure to observe the following precautions to prevent operation failure, malfunction, or adverse effects on the performance and functions of the product. Not doing so may occasionally result in unexpected events.
- 1) The product is designed for indoor use only. Do not use the product outdoors or in any of the following locations.
 - Places subject to splashing liquid or oil atmosphere.
 - Places subject to direct sunlight.
 - Places subject to dust or corrosive gas (in particular, sulfide gas and ammonia gas).
 - Places subject to intense temperature change.
 - Places subject to icing and condensation.
 - Places subject to vibration and large shocks.
 - 2) Use/store within the rated temperature and humidity ranges. Provide forced-cooling if required.
 - Allow heat to escape.
 - Do not block the area around the product.
 - Do not block the ventilation holes on the product.
 - 3) Use specified size (M3.5, width 7.2 mm or less) crimped terminals for wiring. To connect bare wires to the terminal block, use copper braided or solid wires with a gage of AWG24 to AWG18 (equal to a cross-sectional area of 0.205 to 0.632 mm²). (The stripping length is 5 to 6 mm.). Use two wires of same size and type, or two crimped terminals can be inserted into a single terminal.
 - 4) Be sure to wire properly with correct polarity of terminals.
 - Do not wire any of the I/O terminals incorrectly.
 - Do not wire the terminals which are not used.
 - The voltage output (relay) is not electrically isolated from the internal circuits. When using a grounded temperature sensor, do not connect any of the control output terminals to ground. Otherwise unwanted current paths will cause measurement errors.
 - 5) Allow as much space as possible between the controller and devices that generate a powerful high-frequency or surge. Separate the high-voltage or large-current power lines from other lines, and avoid parallel or common wiring with the power lines when you are wiring to the terminals.
 - 6) Use this product within the rated load and power supply.
 - Make sure that the rated voltage is attained within two seconds of turning ON the power using a switch or relay contact. If the voltage is applied gradually, the power may not be reset or output malfunctions may occur.
 - 7) When using PID operation (self-tuning), turn ON the power supply to the load at the same time or before turning the power supply to the Temperature Controller ON.
 - 8) Design system (control panel, etc) considering the 2 second of delay that the controller's output to be set after power ON.
 - 9) A switch or circuit breaker should be provided close to this unit. The switch or circuit breaker should be with easy reach of the operator and be a disconnecting means for this unit.
 - 10) Make sure that the Controller has 30 minutes or more to warm up after turning ON the power before starting actual control operations to ensure the correct temperature display.
 - 11) Be sure that the platinum resistance thermometer type and the input type set on the Temperature Controller are the same. When extending the thermometer lead wires always use compensating conductors suitable for the type of thermometer. Do not extend the lead wires on a platinum resistance thermometer. Use only low-resistance wire (5 Ω max. per line) for lead wires and make sure that the resistance is the same for all three wires.
 - 12) Static electricity can damage internal components. Always touch grounded metal to discharge any static electricity before handling the Temperature Controller. When drawing out the controller from the case, do not touch the electronic components or patterns on the board with your hand. Hold the Temperature Controller by the edge of the front panel when handling it.
 - 13) Do not use paint thinner or similar chemical to clean with. Use standard grade alcohol.
 - 14) Use tools when separating parts for disposal.

Safety Precautions

Key to Warning Symbols

CAUTION Indicates a potentially hazardous situation which, if not avoided, is likely to result in minor or moderate injury or property damage. Read this manual carefully before using the product.

Mounting

Dimensions

E5CS-U (mm)

In the pack:
- Main unit
- Mounting bracket
- Instruction manual
- °C/°F labels, Specifications entry label *1

*1 When changing the display unit, attach the °C/°F label over the previous °C/°F label. Enter the settings on the specifications entry label and use it to manage the settings.

Terminal Layout

● E5CS-R□□, -□□□ (No alarm output type)
Suitable socket is P2CF-08□□ or P3G-08

Control output
Voltage output 12V DC 21mA
Relay output 1 to 250V AC 3A (resistive load)

● E5CS-R1□□, -R2□□, -□□□□, -□2□□□ (Alarm output type)
Suitable socket is P2CF-11□□ or P3GA-11

Control output
Voltage output 12V DC 21mA
Relay output 1 to 250V AC 3A (resistive load)
Alarm output (relay output) 250V AC 1A (resistive load)
Alarm 1
Alarm 2

Do not use
Thermistor
Platinum resistance thermometer

Names of Front Parts

● Display
LED deviation indicators
Temperature indicator
Output operation indicator
Alarm output operation indicator
Mode indicators
Mode key
Front door open/close notch
Front door
Down key

Temperature indicator
The present temperature, set temperature, alarm set temperature, or input shift value is displayed.

LED deviation indicators
▲: Lit when the difference between the present temperature and the set temperature is larger than +1% FS (+0.25% FS for TCrP1 multi-input models).

■: Lit when the difference between the present temperature and the set temperature is within ±1% FS (±0.25% FS for TCrP1 multi-input models).

▼: Lit when the difference between the present temperature and the set temperature is smaller than -1% FS (-0.25% FS for TCrP1 multi-input models).

ST or AT will flash on the temperature indicator when self-tuning or auto-tuning is being performed.

Output operation indicator
OUT: Control output indicator
Li when the output function is ON; not lit when the output function is OFF.

Alarm output operation indicator
ALM1: Alarm 1 indicator
Li when the alarm 1 function is ON.
ALM2: Alarm 2 indicator
Li when the alarm 2 function is ON.

Mode indicators
SP: Li when the set temperature is displayed.
ALM: Li when the alarm set temperature is displayed.

Mode key
Switches the display between the present temperature, set temperature, alarm set temperature, and input shift value.

Up key / Down key
The set temperature, alarm set temperature, or input shift value will increase when the Up Key is pressed. The set temperature, alarm set temperature, or input shift value will decrease when the Down Key is pressed.

● Switch
Pull forward on the front door open/close notch on the right of the front panel to open the front door.
Open the front door only when setting the switches. Do not open it at any other time.

● Protection switch
The protection switch can be turned ON to disable the Up and Down keys and prevent setting mistakes.
The Mode key, however, will operate even when the protection switch is ON (i.e., the display can be switched between the present temperature, set temperature, alarm set temperature, and input shift value).
The default is "OFF".

Installation Diagrams

● Flush mounting (Panel cutout)

Individual mounting (mm)
45^{+0.6}
60 min.

Side-by-side mounting (waterproof not possible) (mm)
(48 x number of units - 2.5)^{±0.2}
42^{+0.2}

Recommended panel thickness is 1 to 4 mm.

Insert the controller through the hole in the panel. Push the mounting bracket on from the rear and fasten temporarily, removing any gap between the controller, panel and mounting bracket. Finally, secure two fixing screws alternately keeping the torque to between 0.29 to 0.39 N·m.
Refer to the dimension diagram for the mounting status.

When mounting more than one Temperature Controller, be sure that the heat generated by the Temperature Controllers does not cause the ambient temperature to exceed the specified value.

Close side-by-side mounting is possible in one direction only, either surface or flush mounting.

When mounting plural units in vertical arrangement, leave space of approx. 20 mm above and below the mounting socket.

SELF-DIAGNOSTIC FUNCTION

If an error occurs, it will be displayed on the temperature display. Check the type of error and correct the error accordingly.

Display	Error	Meaning	Action	Control output	Reverse	Normal
FFF	Over/low limit error	The temperature has risen beyond the set temperature range. With Thermistor types, the sensor is shorted.		OFF	ON	
---	Underflow error	The temperature has fallen below the underflow range. With Thermistor types, the sensor is disconnected.		ON	OFF	
FFF (flashing)	Sensor error	The temperature has risen beyond the underflow temperature. The thermistor or platinum resistance thermometer has failed. TCrP multi-input modes: A temperature sensor error has occurred at a temperature higher than the set temperature range.	Check the wiring of inputs, disconnections, shorts and input type.	OFF	OFF	
(flashing)	Thermistor error	The temperature has fallen below the underflow temperature. The polarity (positive and negative) of thermistor has been reversed. The platinum resistance thermometer has failed. TCrP multi-input modes: A temperature sensor error has occurred at a temperature higher than the set temperature range.		OFF	OFF	
E 11	Memory error	Memory has failed.	Alter the connection of input terminals. Turn power OFF then back ON again.	OFF	OFF	

If the input value exceeds the display limit (-99 to 1999), though it is within the control range, [CC] will be displayed under -99 and [99] above 1999.

Under these conditions, control output and alarm output will operate normally.

*1 Alarm output (Modes with alarm output type only)
- The alarm output will operate as an abnormally high temperature alarm when FFF is displayed (flashes).
- The alarm output will operate as an abnormally low temperature alarm when --- is displayed (flashes).
*2 Errors are displayed only when the present temperature is being displayed.
Errors will not be displayed if the set temperature, alarm set temperature, or input shift value is displayed.
*3 Sensor error detection function is not provided for thermistor type.

Conformance to EN/IEC Standards

This is a class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.

Conformance to Safety Standards

Reinforced insulation is provided between input power supply, relay outputs, and between other terminals.

Operation

Step 1 Set the operating specifications with the switches.

● Control mode selector switch

Switch	Function	OFF	ON
1	PID ON/OFF	ON/OFF control	2-PID control
2	Control period	20 seconds	2 seconds
3	Forward/reverse operation	Reverse	Normal
4	Input shift	Thermocouple, K, J	Thermocouple, K, L
5	Thermometer replacement	Platinum resistance thermometer, Pt100 Multi-input; Thermocouple	Platinum resistance thermometer, Pt100 Multi-input; Platinum resistance thermometer
6	Selection	°C	°F

● Alarm mode selector switch

SW No.	Alarm type	Alarm output
0,8	No alarm function	Output off
1	Deviation upper/lower limit	on/off
2	Deviation upper limit	on/off
3	Deviation lower limit	on/off
4	Deviation upper/lower range	on/off
5	Deviation upper limit standby sequence ON	on/off
6	Deviation upper limit standby sequence OFF	on/off
7	Deviation lower limit standby sequence ON	on/off
8	Absolute value upper limit	on/off

For alarms 1 to 7, set the alarm value (X) to the deviation from the set point. For alarm 8, set the alarm value (Y) to the absolute value from 0°C/°F.
The default is "2" (Deviation upper limit).
The only type of alarm supported for alarm 2 is an upper limit alarm.

Thermocouple/platinum resistance thermometer (multi-input) (E5CS-□□□□)

Control mode selector switch No.5: OFF

Input	Setting	Setting range
K	0	0 to 1999 / 999 to 1999
J	1	0.0 to 199.9 / 99.9 to 150.0
L	3	0.0 to 199.9 / 99.9 to 150.0
L	4	99.9 to 850.0 / 99.9 to 1500.0
L	5	99.9 to 400.0 / 99.9 to 700.0
L	6	0.0 to 199.9 / 0.0 to 199.9
N	8	99.9 to 400.0 / 99.9 to 700.0
R	9	0.0 to 1700.0 / 0.0 to 1999.0

Control mode selector switch No.5: ON

Input	Setting	Setting range
Pt100	0	99.9 to 850.0 / 99.9 to 1500.0
Pt100	1	0.0 to 199.9 / 0.0 to 199.9
Pt100	2	99.9 to 99.9 / 99.9 to 99.9
Pt100	3	0 to 200 / 0 to 200
Pt100	4	0 to 400 / 0 to 400
Pt100	5	99.9 to 500 / 99.9 to 900
Pt100	6	0.0 to 199.9 / 0.0 to 199.9
Pt100	7	99.9 to 99.9 / 99.9 to 99.9
Pt100	8	0 to 200 / 0 to 200
Pt100	9	0 to 400 / 0 to 400

● Temperature range selector switch

Thermocouple type (E5CS-□□□□)

Input	Setting	Setting range
JPt100	0	-50 to 50 / -50 to 50
Pt100	1	0.0 to 50.0 / 0.0 to 50.0
Pt100	2	20 to 90 / 20 to 90
Pt100	3	0.0 to 99.9 / 0.0 to 99.9
Pt100	4	0 to 200 / 0 to 200
Pt100	5	0 to 300 / 0 to 300
Pt100	6	0 to 400 / 0 to 400
Pt100	7	0 to 500 / 0 to 500
Pt100	8	0 to 400 / 0 to 800
Pt100	9	0.0 to 199.9 / 0.0 to 199.9

Platinum resistance thermometer type (E5CS-□□□□)

Input	Setting	Setting range
JPt100	0	-50 to 50 / -50 to 100
Pt100	1	0 to 100 / 0 to 200
Pt100	2	100 to 150 / 100 to 300
Pt100	3	100 to 200 / 200 to 400
Pt100	4	150 to 300 / 300 to 600
Pt100	5	-50 to 50 / -50 to 100
Pt100	6	0 to 100 / 0 to 200
Pt100	7	50 to 150 / 100 to 300
Pt100	8	100 to 200 / 200 to 400
Pt100	9	150 to 300 / 300 to 600

Thermistor type (E5CS-□□□□)

Input	Setting	Setting range
G	0	-50 to 50 / -50 to 100
G	1	0 to 100 / 0 to 200
G	2	100 to 150 / 100 to 300
G	3	100 to 200 / 200 to 400
G	4	150 to 300 / 300 to 600
G	5	-50 to 50 / -50 to 100
G	6	0 to 100 / 0 to 200
G	7	50 to 150 / 100 to 300
G	8	100 to 200 / 200 to 400
G	9	150 to 300 / 300 to 600

* The default is "2".

Step 2 Set the control temperature.

● Temperature indication

POWER ON

1. Present temperature *1

2. Set temperature SP indicator lit.

3. Alarm value *1 *2 ALM indicator lit.

4. Alarm value *2 *2 ALM indicator flashes.

5. Input shift value *3

*1 To start AT (auto-tuning), press and hold the Up and Down keys simultaneously for at least 2 seconds while the temperature is displayed on the temperature indicator.
*2 Displayed only for models with alarms. When alarm mode selector switch is set to 0 or 9, no alarm temperature is displayed.
*3 The only type of alarm supported for Alarm 2 is an upper limit alarm.
*4 Input shift value is not displayed when pin 4 of control mode selector switch is set to OFF.

OMRON EUROPE B.V.
Wegalaan 67-69, NL-2132 JD Hoofddorp The Netherlands
Phone 31-2356-81-300
FAX 31-2356-81-388

OMRON ELECTRONICS LLC
One Commerce Drive Schaumburg, IL 60173-5302 U.S.A.
Phone 1-847-843-7900
FAX 1-847-843-7787

OMRON ASIA PACIFIC PTE. LTD.
No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark, Singapore 119967
Phone 65-6835-3011
FAX 65-6835-2711

OMRON Corporation
Shiojiki Horikawa, Shimogyo-ku, Kyoto 600-8530 JAPAN