



DeviceNet™ Analog I/O Terminals

Replace Guide From DRT2-AD/DA to R7 Series

OMRON

DRT2-AD04

DRT2-DA02

MG CO., LTD.

Remote I/O R7 Series

R7D-SV4

R7D-YV2

R7D-YS2

A large blue rectangular graphic with a white border, containing the text "Replace Guide" in white. The text is centered within the rectangle.

Replace
Guide

■Introduction

This document is intended for experienced users who have designed remote I/O communication systems using DeviceNet,

This is the summary of points to smoothly transfer the system to R7D-SV4/R7D-YV2/YS2 manufactured by MG CO., LTD.

This document is a summary of only the points. For detailed operating procedures, refer to the documentation and technical documentation in "7. REFERENCE INFORMATION".

■Target readers

This guide is written for the following:

With electrical knowledge (electrical engineers or equivalent knowledge)

- Those responsible for the installation of factory automation equipment
- Those designing FA systems
- Those who manage factory automation sites

Windows is registered trademarks of Microsoft Corporation in the USA and other countries.

DeviceNet™ is the trademarks of ODVA.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.

Terms and Conditions Agreement

Warranties

(a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

(b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <http://www.omron.com/global/> or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Table of Contents

Terms and Conditions Agreement	3
Intended Customer.....	6
Object product	6
1 Comparing DRT2-AD04/DA02 and R7D-SV4/YV2/YS2 specifications	7
1.1 Analog input terminal	7
1.2 Analog Output Terminals.....	9
1.3 EXTERNAL DIMENSIONS.....	10
2 Switch setting method	11
2.1 DRT2-AD04 and R7D-SV4.....	11
2.2 DRT2-DA02 and R7D-YV2	13
2.3 DRT2-DA02 and R7D-YS2.....	14
3 Wiring method.....	15
3.1 DRT2-AD04 and R7D-SV4.....	15
3.2 DRT2-DA02 and R7D-YS2.....	16
3.3 DRT2-DA02 and R7D-YV2	17
4 Setting by PC Configurator Software	18
5 Replacing the Unit.....	21
5.1 Replacement of Unit at Fixed Assignment	21
5.2 Replacement of Unit at Free Assignment	23
6 Terminology and definitions.....	28
7 Reference information	29
8 Notes.....	30
9 Revision History.....	30

Intended Customer

- A customer who has previously been designed a remote I/O communication system using DeviceNet and will be responsible for replacing the unit from DRT2-AD04/DA02 to R7D-SV4/YV2/YS2 in the future.
- Omron or your retailer's sales representative or SE that supports the introduction of the above customer.

Object product

Name	Type
DeviceNet master unit	Model CJ1W-CRM21 Model CS1W-CRM21
DeviceNet analogue-in terminals	Model DRT2-AD04
DeviceNet Analogue Out Terminals	Model DRT2-DA02
MG Co., Ltd. Remote I/OR7 Series DC voltage/current input module	Model R7D-SV4
MG Co., Ltd. Remote I/OR7 Series DC voltage output unit	Model R7D-YV2
MG Co., Ltd. Remote I/OR7 Series DC current output unit	Model R7D-YS2
Included in CX-Programmer (Included in CX-One)	
Included in CX-Integrator (Included in CX-One)	
MG Co., Ltd. Configuration software	Model R7CON
MG Co., Ltd. PC configuration cable	Model COP-US

1 Comparing DRT2-AD04/DA02 and R7D-SV4/YV2/YS2 specifications

This chapter compares the functions and specific cations of DRT2-AD04/DA02 and R7D-SV4/YV2/YS2.

1.1 Analog input terminal

Item	DRT2-AD04		R7D-SV4	
Number of analog input points	4 points			
Input range	Voltage		Voltage	
	Current		Current	
	0 ~ 5V	0 ~ 20mA	0~5V	0~20mA
	1 ~5V	4~ 20mA	1~5V	4~20mA
	0 ~ 10V		-5V~+5V	-20~+20mA
10 ~ +10V		0~10V		
		-10V~+10V		
		-1~+1V		
		0~1V		
		-0.5~+0.5V		
AD conversion cycle	4 points 4ms or less		4 points 10m s,20ms,40ms,80ms	
Resolution	1/6000		1/10000	
Unit power supply	Supplied from communication power			
Accuracy		Voltage	Current	Accuracy Conversion Speed ±0.1% 80ms ±0.2% 40ms ±0.4% 20ms ±0.8% 10ms
	25°C	±0.3%	±0.4%	
	0~55°C	±0.6%	±0.8%	
Assignment data to master	Default: Input analog for 4 points The following data can be assigned by setting from the Configurator. Peak value, Bottom value, Top value, Barre value, Rate of change value, Comparator result, General status, etc.		4 input analog points	
Input point switching (A/D conversion point setting)	Yes Depending on the setting from the Configurator: 1 to 4 points)		None	
Input range switching	With DIP switch setting: Input 0, 1 Common, Input 2, 3 Common Depending on the setting from the Configurator : Input 0 to 3 can be set individually.		With DIP switch setting: Common to inputs 0 to 3 Using the configuration software (R7CON): Input 0 to 3 can be set individually.	
Node address setting	Rotary switch, Or set by the Configurator		Rotary switch	
Dialing speed	Automatically follow master sets		Rotary switch. Automatic tracking to the master setting is also possible by setting the rotary switch.	
Averaging function	Yes		None	
Disconnection detection function				
Scaling function				
Offset compensation function				
Peak Bottom Hold function				
Top valley hold function				
Conversion rate				


calculation function		
Comparator function		
User calibration function		
Integral function		
Last maintenance day function		

1.2 Analog Output Terminals


Item	DRT2-DA02	R7D-YV2	R7D-YS2	
Number of analog output points	2 points			
Output range	Voltage	Current	Voltage	Current
	0 ~ 5V 1 ~ 5V 0 ~ 10V - 10 ~ +10V	0 ~ 20mA 4 ~ 20mA	0~5V 1~5V -5V~+5V 0~10V -10V~+10V -1~+1V 0~1V -0.5~+0.5V	4~20mA
AD conversion cycle	2 points 4ms or less		2 points 250ms	
Resolution	1/6000		1/10000	
Unit power supply	Supplied from communication power			
Accuracy	25°C	±0.6%	±0.1%	
	0~55°C	±0.8%		
Assignment data to master	Default: Output analog value of 2 points General-purpose status can be assigned by setting from the Configurator.		Output analog value for two points	
Output range switching	Depends on the DIP switch setting or the setting from the Configurator.		DIP switch setting or setting by the configuration software (R7CON)	None
Node address setting	Rotary switch, Or set by the Configurator		Rotary switch	
Dialing speed	Automatically follow master sets		Rotary switch Automatic tracking to the master setting is also possible by setting the rotary switch.	
Output condition at the time of communication error	Depending on the setting from the Configurator		DIP switch	
Scaling function	Yes		None	
User calibration function				
Scaling function				
Integral function				
Last maintenance day function				

1.3 EXTERNAL DIMENSIONS

R7D-SV4



R7D-YV2/YS2








- 2 Switch setting method
 DRT2-AD04/DA02 and R7D-SV4/YV2/YS2 settings are described with both units.
 I will explain it.



Safety Key Points

Be sure to turn off the power to the slave before making sets.

2.1 DRT2-AD04 and R7D-SV4

DRT2-AD04	R7D-SV4
<p>Set the node address and input range.</p> <ul style="list-style-type: none"> • Model DRT2-AD04  <p>Rotary switches. Set the node address.</p> <p>DeviceNet indicators</p> <p>DIP switch Sets the input ranges.</p> <p>Communications connector</p> <p>Removeable terminal block</p> <p>Setting the Node Address</p>  <p>Node address setting (one's digit)</p> <p>Node address setting (ten's digit)</p> <p>Setting the Baud Rate</p> <p>There is no setting.</p>	<p>Set the node address, communication speed, input range, and conversion speed/accuracy.</p> <ul style="list-style-type: none"> • Model R7D-SV4  <p>(A) Status Indicator LED (B) Node Address Setting Rotary SW (C) Baud Rate Setting Rotary SW (D) Operating Mode Setting DIP SW (SW1) (E) PC Configurator Jack (F) DeviceNet, Power Supply Terminals (G) Input Terminals</p> <p>Setting the Node Address</p>  <p>Factory setting : 00</p> <p>Node Address Setting (x1)</p> <p>Node Address Setting (x10)</p> <p>Setting the Baud Rate</p>  <p>0 : 125 kbps (factory setting) 1 : 250 kbps 2 : 500 kbps 3 thr. 9 : Auto-tracking</p> <p>Baud Rate Setting</p>

Setting input range

Pin No.	Setting	Specifications
1	Input Terminal: Input range setting for Inputs 0 and 1.	Default setting: All pins OFF
2		
3		
4	Input Terminal: Input range setting for Inputs 2 and 3.	Default setting: All pins OFF
5		
6		
7	AD conversion data format setting	ON: Signed binary OFF: Two's complement
8	Range setting method	OFF: Use Configurator. ON: Use DIP switch. The other DIP switch settings are disabled when pin 8 is OFF. Default setting: OFF

■ Inputs 0 and 1 (Shared Setting)

Signal range	Pin 1	Pin 2	Pin 3
0 to 5 V	OFF	OFF	OFF
1 to 5 V	ON	OFF	OFF
0 to 10 V	OFF	ON	OFF
-10 to 10 V	ON	ON	OFF
4 to 20 mA	OFF	OFF	ON
0 to 20 mA	ON	OFF	ON
Cannot set for other ranges.	---	---	---

■ Inputs 2 and 3 (Shared Setting)

Signal range	Pin 4	Pin 5	Pin 6
0 to 5 V	OFF	OFF	OFF
1 to 5 V	ON	OFF	OFF
0 to 10 V	OFF	ON	OFF
-10 to 10 V	ON	ON	OFF
4 to 20 mA	OFF	OFF	ON
0 to 20 mA	ON	OFF	ON
Cannot set for other ranges.	---	---	---

Conversion Speed/Accuracy Setting

There is no setting.

Setting input range

SW1-5	SW1-6	SW1-7	SW1-8	INPUT RANGE
OFF	OFF	OFF	OFF	-10 – +10V DC (*)
ON	OFF	OFF	OFF	-5 – +5V DC
OFF	ON	OFF	OFF	-1 – +1V DC
ON	ON	OFF	OFF	0 – 10V DC
OFF	OFF	ON	OFF	0 – 5V DC
ON	OFF	ON	OFF	1 – 5V DC
OFF	ON	ON	OFF	0 – 1V DC
ON	ON	ON	OFF	-0.5 – +0.5V DC
ON	OFF	OFF	ON	-20 – +20mA DC
OFF	ON	OFF	ON	4 – 20mA DC
ON	ON	OFF	ON	0 – 20mA DC
ON	ON	ON	ON	PC Configurator setting

Conversion Speed/Accuracy Setting


SW1-3	SW1-4	CONVERSION RATE / ACCURACY
OFF	OFF	80 msec. / $\pm 0.1\%$ (*)
ON	OFF	40 msec. / $\pm 0.2\%$
OFF	ON	20 msec. / $\pm 0.4\%$
ON	ON	10 msec. / $\pm 0.8\%$

2.2 DRT2-DA02 and R7D-YV2


DRT2-DA02

Set the node address and output range

- Model DRT2-DA02



Setting the Node Address



Setting the Baud Rate

There is no setting.

Output condition at the time of communication error

Set in the Configurator.

Output range setting

■ Output 0

Signal range	Pin 1	Pin 2	Pin 3
0 to 5 V	OFF	OFF	OFF
1 to 5 V	ON	OFF	OFF
0 to 10 V	OFF	ON	OFF
-10 to 10 V	ON	ON	OFF
4 to 20 mA	OFF	OFF	ON
0 to 20 mA	ON	OFF	ON


■ Output 1

Signal range	Pin 4	Pin 5	Pin 6
0 to 5 V	OFF	OFF	OFF
1 to 5 V	ON	OFF	OFF
0 to 10 V	OFF	ON	OFF
-10 to 10 V	ON	ON	OFF
4 to 20 mA	OFF	OFF	ON
0 to 20 mA	ON	OFF	ON

R7D-YV2


Set the node address, communication speed, output at communication interruption, and output range.

- Model R7D-YV2




- (A) Status Indicator LED
- (B) Node Address Setting Rotary SW
- (C) Baud Rate Setting Rotary SW
- (D) Operating Mode Setting DIP SW (SW1)
- (E) PC Configurator Jack
- (F) DeviceNet, Power Supply Terminals
- (G) Output Terminals

Setting the Node Address



Setting the Baud Rate



Output condition at the time of communication error

SW1-4	OUTPUT AT THE LOSS OF COMMUNICATION
OFF	Reset the output (to -15% or approx. -11.5V DC)
ON	Hold the output (*) (maintains the last data received normally)

Output range setting


SW1-5	SW1-6	SW1-7	SW1-8	OUTPUT RANGE
OFF	OFF	OFF	OFF	-10 – +10V DC (*)
ON	OFF	OFF	OFF	-5 – +5V DC
OFF	ON	OFF	OFF	-1 – +1V DC
ON	ON	OFF	OFF	0 – 10V DC
OFF	OFF	ON	OFF	0 – 5V DC
ON	OFF	ON	OFF	1 – 5V DC
OFF	ON	ON	OFF	0 – 1V DC
ON	ON	ON	OFF	-0.5 – +0.5V DC
ON	ON	ON	ON	PC Configurator setting

2.3 DRT2-DA02 and R7D-YS2


DRT2-DA02

Set the node address and output range.

- Model DRT2-DA02



Setting the Node Address



Setting the Baud Rate

There is no setting.

Output condition at the time of communication error

Set in the Configurator.

Output range setting

■ Output 0

Signal range	Pin 1	Pin 2	Pin 3
0 to 5 V	OFF	OFF	OFF
1 to 5 V	ON	OFF	OFF
0 to 10 V	OFF	ON	OFF
-10 to 10 V	ON	ON	OFF
4 to 20 mA	OFF	OFF	ON
0 to 20 mA	ON	OFF	ON


■ Output 1

Signal range	Pin 4	Pin 5	Pin 6
0 to 5 V	OFF	OFF	OFF
1 to 5 V	ON	OFF	OFF
0 to 10 V	OFF	ON	OFF
-10 to 10 V	ON	ON	OFF
4 to 20 mA	OFF	OFF	ON
0 to 20 mA	ON	OFF	ON

R7D-YS2


Set the node address, communication speed, output at communication interruption, and output range.

- Model R7D-YS2




- (A) Status Indicator LED
- (B) Node Address Setting Rotary SW
- (C) Baud Rate Setting Rotary SW
- (D) Operating Mode Setting DIP SW (SW1)
- (E) PC Configurator Jack
- (F) DeviceNet, Power Supply Terminals
- (G) Output Terminals

Setting the Node Address



Setting the Baud Rate



Output condition at the time of communication error

SW1-4	OUTPUT AT THE LOSS OF COMMUNICATION
OFF	Reset the output (to -15% or approx. -11.5V DC)
ON	Hold the output (*) (maintains the last data received normally)

Output range setting


There is no setting.

3 Wiring method

3.1 DRT2-AD04 and R7D-SV4


DRT2-AD04

Wire each input unit according to the voltage input or current input as shown below.




R7D-SV4

Wire each input unit according to the voltage input or current input as shown below.



NO.	ID	FUNCTION	NO.	ID	FUNCTION
1	VH0	Wide span volt. 0	10	VL0	Narrow span volt. 0
2	COM0	Common 0	11	I0	Current range 0
3	VH1	Wide span volt. 1	12	VL1	Narrow span volt. 1
4	COM1	Common 1	13	I1	Current range 1
5	NC	No connection	14	NC	No connection
6	VH2	Wide span volt. 2	15	VL2	Narrow span volt. 2
7	COM2	Common 2	16	I2	Current range 2
8	VH3	Wide span volt. 3	17	VL3	Narrow span volt. 3
9	COM3	Common 3	18	I3	Current range 3

Terminal connection diagram




3.2 DRT2-DA02 and R7D-YS2

DRT2-DA02					R7D-YS2																																																												
<p>Wire each output unit according to the voltage output or current output as shown below.</p> <p>Note: The voltage or current output signal ranges are set on the DIP switch or from the Configurator.</p>					<table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="padding: 2px;">6</td><td style="padding: 2px;">7</td><td style="padding: 2px;">8</td><td style="padding: 2px;">9</td><td style="padding: 2px;">10</td> </tr> <tr> <td style="padding: 2px;">NC</td><td style="padding: 2px;">IO</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">I1</td><td style="padding: 2px;">NC</td> </tr> <tr> <td style="padding: 2px;">1</td><td style="padding: 2px;">2</td><td style="padding: 2px;">3</td><td style="padding: 2px;">4</td><td style="padding: 2px;">5</td> </tr> <tr> <td style="padding: 2px;">NC</td><td style="padding: 2px;">COM0</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">COM1</td><td style="padding: 2px;">NC</td> </tr> </table> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse; width: 100%;"> <thead> <tr> <th style="padding: 2px;">NO.</th><th style="padding: 2px;">ID</th><th style="padding: 2px;">FUNCTION</th><th style="padding: 2px;">NO.</th><th style="padding: 2px;">ID</th><th style="padding: 2px;">FUNCTION</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">1</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">No connection</td><td style="padding: 2px;">6</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">No connection</td> </tr> <tr> <td style="padding: 2px;">2</td><td style="padding: 2px;">COM0</td><td style="padding: 2px;">Common 0</td><td style="padding: 2px;">7</td><td style="padding: 2px;">IO</td><td style="padding: 2px;">Current 0</td> </tr> <tr> <td style="padding: 2px;">3</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">No connection</td><td style="padding: 2px;">8</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">No connection</td> </tr> <tr> <td style="padding: 2px;">4</td><td style="padding: 2px;">COM1</td><td style="padding: 2px;">Common 1</td><td style="padding: 2px;">9</td><td style="padding: 2px;">I1</td><td style="padding: 2px;">Current 1</td> </tr> <tr> <td style="padding: 2px;">5</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">No connection</td><td style="padding: 2px;">10</td><td style="padding: 2px;">NC</td><td style="padding: 2px;">No connection</td> </tr> </tbody> </table> 					6	7	8	9	10	NC	IO	NC	I1	NC	1	2	3	4	5	NC	COM0	NC	COM1	NC	NO.	ID	FUNCTION	NO.	ID	FUNCTION	1	NC	No connection	6	NC	No connection	2	COM0	Common 0	7	IO	Current 0	3	NC	No connection	8	NC	No connection	4	COM1	Common 1	9	I1	Current 1	5	NC	No connection	10	NC	No connection
6	7	8	9	10																																																													
NC	IO	NC	I1	NC																																																													
1	2	3	4	5																																																													
NC	COM0	NC	COM1	NC																																																													
NO.	ID	FUNCTION	NO.	ID	FUNCTION																																																												
1	NC	No connection	6	NC	No connection																																																												
2	COM0	Common 0	7	IO	Current 0																																																												
3	NC	No connection	8	NC	No connection																																																												
4	COM1	Common 1	9	I1	Current 1																																																												
5	NC	No connection	10	NC	No connection																																																												

3.3 DRT2-DA02 and R7D-YV2

DRT2-DA02	R7D-YV2
-----------	---------


Wire each output unit according to the voltage output or current output as shown below.



Note: The voltage or current output signal ranges are set on the DIP switch or from the Configurator.

6	7	8	9	10
NC	VH0	VL0	VH1	VL1
1	2	3	4	5
NC	COM0	COM0	COM1	COM1

NO.	ID	FUNCTION	NO.	ID	FUNCTION
1	NC	No connection	6	NC	No connection
2	COM0	Common 0	7	VH0	Wide span volt. 0
3	COM0	Common 0	8	VL0	Narrow span volt. 0
4	COM1	Common 1	9	VH1	Wide span volt. 1
5	COM1	Common 1	10	VL1	Narrow span volt. 1



Output Connection Examples









4 Setting by PC Configurator Software

For the R7D series manufactured by MG Co., Ltd. the range of each channel can be set by using the PC Configurator software.


The following sections describe how to set the range for each channel.

R7CON							
<p>Operating Environment</p> <ul style="list-style-type: none"> WindowsXP, Windows7 (32-bit/64-bit) or Windows10 (32-bit/64-bit) installed correctly A DOS/V compatible personal computer. <p>To connect the device to the PC communication port, the configurator connection cable shown in the table below is required.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Connection port</th> <th>CONFIGURATOR CONNECTION CABLE FORMAT</th> </tr> </thead> <tbody> <tr> <td>RS-232-C</td> <td>MCN-CON</td> </tr> <tr> <td>USB</td> <td>COP-US</td> </tr> </tbody> </table> <p>Preparing to use R7CON</p> <p>To use the Configurator software, you must install the software.</p> <p>To write the configured data to the control module, the PC and the remote I/O converter must be properly connected.</p> <p>Installing R7CON</p> <ol style="list-style-type: none"> ① Start Windows. ② Download the Configurator Software from the website of MG Co., Ltd. Institute (https://www.mgco.jp/download_w/dl_softwareE.html) and save it on the local disc of your PC. ③ Check the size and version of the downloaded file. File name: R7CON_R□.exe or R7CON_R□.zip □ contains the version. ④ Double-click to create R7CON folders. ⑤ Execute setup.exe in R7CON folders and follow the instructions of the installer to install. <p>Connection between PC and R7D</p> <ol style="list-style-type: none"> ① Connect the Configurator Kick ^ to the COM port or USB of the PC. ② Connect the Configurator Connection Cable (Stereo Jack Side) to the setting connector on the R7D. 		Connection port	CONFIGURATOR CONNECTION CABLE FORMAT	RS-232-C	MCN-CON	USB	COP-US
Connection port	CONFIGURATOR CONNECTION CABLE FORMAT						
RS-232-C	MCN-CON						
USB	COP-US						

1	<p>Setting the dip switch To R7D-SV4/YV2's SW1-5, 6, 7, and 8 Turns all ON.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>SW1-5</th> <th>SW1-6</th> <th>SW1-7</th> <th>SW1-8</th> <th>OUTPUT RANGE</th> </tr> </thead> <tbody> <tr><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td><td>-10 – +10V DC (*)</td></tr> <tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>-5 – +5V DC</td></tr> <tr><td>OFF</td><td>ON</td><td>OFF</td><td>OFF</td><td>-1 – +1V DC</td></tr> <tr><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>0 – 10V DC</td></tr> <tr><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td><td>0 – 5V DC</td></tr> <tr><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td><td>1 – 5V DC</td></tr> <tr><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>0 – 1V DC</td></tr> <tr><td>ON</td><td>ON</td><td>ON</td><td>OFF</td><td>-0.5 – +0.5V DC</td></tr> <tr style="border: 2px solid red;"><td>ON</td><td>ON</td><td>ON</td><td>ON</td><td>PC Configurator setting</td></tr> </tbody> </table>	SW1-5	SW1-6	SW1-7	SW1-8	OUTPUT RANGE	OFF	OFF	OFF	OFF	-10 – +10V DC (*)	ON	OFF	OFF	OFF	-5 – +5V DC	OFF	ON	OFF	OFF	-1 – +1V DC	ON	ON	OFF	OFF	0 – 10V DC	OFF	OFF	ON	OFF	0 – 5V DC	ON	OFF	ON	OFF	1 – 5V DC	OFF	ON	ON	OFF	0 – 1V DC	ON	ON	ON	OFF	-0.5 – +0.5V DC	ON	ON	ON	ON	PC Configurator setting
SW1-5	SW1-6	SW1-7	SW1-8	OUTPUT RANGE																																																
OFF	OFF	OFF	OFF	-10 – +10V DC (*)																																																
ON	OFF	OFF	OFF	-5 – +5V DC																																																
OFF	ON	OFF	OFF	-1 – +1V DC																																																
ON	ON	OFF	OFF	0 – 10V DC																																																
OFF	OFF	ON	OFF	0 – 5V DC																																																
ON	OFF	ON	OFF	1 – 5V DC																																																
OFF	ON	ON	OFF	0 – 1V DC																																																
ON	ON	ON	OFF	-0.5 – +0.5V DC																																																
ON	ON	ON	ON	PC Configurator setting																																																
2	<p>From the [Start] menu, select [Programs]-[R7CON].</p>																																																			
3	<p>Start R7CON.</p>																																																			

<p>4 Select the COM port by clicking the "Setting" button. The COM port selection screen appears. Select the COM port you want to use, Click the OK button.</p>	
<p>5 After connecting, the initial screen is displayed.</p>	
<p>6 Click Setting2.</p>	
<p>7 This displays the range selection screen.</p>	
<p>8 Select the range to be used from the "Range" pull-down menu.</p>	

R7D-SV4 R7D-YV2

9	Change the required CH range.	
10	Download the configuration	 <p>The screenshot shows the RDC-8V4 software interface. The title bar reads 'RDC-8V4 Version: 0.01' and 'COM1 Connected'. The interface is divided into several sections: 'Monitoring' with 'Start' and 'Stop' buttons; 'Com' with 'Connect', 'Disconnect', and 'Setting' buttons; and 'IO' with 'Upload' and 'Download' buttons. The 'Download' button is highlighted with a red rectangle. The main area displays 'Value' for 'SV4' with four channels: CH 0 (0), CH 1 (10000), CH 2 (7900), and CH 3 (6000). Below this is a 'Setting' section with 'Setting 1' and 'Setting 2' tabs, and a 'Range' section with four dropdown menus, each currently set to '0% to 100%'. At the bottom, there is an 'Output HoldOFF' section with radio buttons for 'Output Hold' and 'Output Clear'.</p>

5 Replacing the Unit



5.1 Replacement of Unit at Fixed Assignment



Safety Key Points




Be sure to turn off the power to the slave before making sets.



1	Check DRT2-AD04/DA02 range.	<div style="text-align: center;">  </div> <p> ■ When DIP switch 8 is OFF, set with the Configurator. Check the range that is being used. </p> <p> ① Double-click the slave to be set on the normal screen, Open the Edit Device Parameters screen. (In the Maintenance Mode screen, right-click-"Parameter"- "Edit") </p> <p> ③ Select the tab for the channel whose range you want to check </p> <div style="border: 1px solid gray; padding: 5px;"> <p style="text-align: center; margin: 0;">Edit Device Parameters</p> <p style="margin: 0;">General Analog Input 0 Analog Input 1 Analog Input 2 Analog Input 3</p> <p style="margin: 0;">I/O Comment : <input type="text"/></p> <p style="margin: 0;">Last Maintenance Date : 2002/01/01 <input type="button" value="Adjustment..."/></p> <p style="margin: 0;">Function Choice</p> <p style="margin: 0;"> <input type="checkbox"/> Moving Average <input type="checkbox"/> Peak/Bottom <input type="checkbox"/> Comparator <input type="checkbox"/> Rate of Change <input type="checkbox"/> Scaling <input type="checkbox"/> Top/Valley <input type="checkbox"/> Cumulated Count </p> <p style="margin: 0;">Range/Data Allocation</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Parameter Name</th> <th style="text-align: left;">Value</th> </tr> </thead> <tbody> <tr style="background-color: #e0f0ff;"> <td>0000 Input Range</td> <td>0 - 5V</td> </tr> <tr> <td>0001 Analog Data1 Allocation</td> <td>Raw Value</td> </tr> <tr> <td>0002 Analog Data2 Allocation</td> <td>Raw Value</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> <p style="margin: 0;"> <small>Help</small> NOTE! Input Range isn't enabled only by changing this parameter. RESET or re-start is required. </p> <p style="margin: 0; text-align: right;">Default : 0 - 5V</p> <p style="margin: 0; text-align: center;"><input type="button" value="Default Setting"/></p> </div> <p> ■ When DIP switch 8 is ON, it is not necessary to check the settings using the DIP switch. </p>	Parameter Name	Value	0000 Input Range	0 - 5V	0001 Analog Data1 Allocation	Raw Value	0002 Analog Data2 Allocation	Raw Value				
Parameter Name	Value													
0000 Input Range	0 - 5V													
0001 Analog Data1 Allocation	Raw Value													
0002 Analog Data2 Allocation	Raw Value													
2	Sets R7D-SV4/YV2 range.	<p> If DRT2-AD04/DA02 range is set to the DIP switch and all channels are set to the same range, use the DIP switch to set R7D-SV4/YV2 range. For details on how to set the DIP switch, refer to "4. Switching." </p> <p> If DRT2-AD04/DA02 range setting is not the same as the Configurator setting or all channels, set R7D-SV4/YV2 range using the PC Configurator software. For details on how to set the PC Configurator software, refer to "4 Setting by PC configuration software". </p>												
3	Sets the node address.	<p>Set the node address of R7D-SV4/YV2/YS2 to the same node address as DRT2-AD04/DA02.</p>												



4	Setting the Baud Rate	 <p>Factory setting : 00</p> <p>Node Address Setting (x1)</p> <p>Node Address Setting (x10)</p> <p>Set the rotary switch to 3 to 9: Automatic follow-up.</p>
5	Connect the unit.	After changing the wiring to the terminal of R7D-SV4/YV2/YS2, connect DeviceNet circuit to the communication connector of DevicNet.
6	Turn on the power.	<p>Check that MS and NS of R7D-SV4/YV2/YS2 are lit in green.</p> 

5.2 Replacement of Unit at Free Assignment



The following procedure shows how to replace DRT2-AD04 allocated in 4ch from 3310Ch with a R7D-SV4.

1	Turn on the PLC.																													
2	Bring PLCs and CX-Integrator online. The device configuration is actually uploaded from DeviceNet to the PC.																													
3	Select the master unit in the network configuration window and double-click it.																													
4	Check that DRT2-AD04 is assigned 8byte from 3310 channels.	 <table border="1" data-bbox="742 1310 1300 1512"> <thead> <tr> <th>#</th> <th>Product Name</th> <th>Out Size</th> <th>Out Ch</th> <th>In Size</th> <th>In Ch</th> <th>C</th> </tr> </thead> <tbody> <tr> <td>#01</td> <td>DRT2-AD04</td> <td>0 Byte</td> <td></td> <td>8 Byte</td> <td>3310:Bi...</td> <td></td> </tr> <tr> <td>#02</td> <td>DRT2-ID08</td> <td>0 Byte</td> <td></td> <td>1 Byte</td> <td>3306:Bi...</td> <td></td> </tr> <tr> <td>#03</td> <td>DRT2-OD08</td> <td>1 Byte</td> <td>3200:Bi...</td> <td>0 Byte</td> <td></td> <td></td> </tr> </tbody> </table>	#	Product Name	Out Size	Out Ch	In Size	In Ch	C	#01	DRT2-AD04	0 Byte		8 Byte	3310:Bi...		#02	DRT2-ID08	0 Byte		1 Byte	3306:Bi...		#03	DRT2-OD08	1 Byte	3200:Bi...	0 Byte		
#	Product Name	Out Size	Out Ch	In Size	In Ch	C																								
#01	DRT2-AD04	0 Byte		8 Byte	3310:Bi...																									
#02	DRT2-ID08	0 Byte		1 Byte	3306:Bi...																									
#03	DRT2-OD08	1 Byte	3200:Bi...	0 Byte																										


5	Check DRT2-AD04 range.	 <p>■ When DIP switch 8 is OFF, set with the Configurator. Check the range that is being used.</p> <p>① Double-click the slave to be set on the normal screen. Then open the Edit Device Parameters screen. (In the Maintenance Mode screen, right-click-"Parameter"- "Edit")</p> <p>② Select the tab for the channel whose range you want to check.</p>  <p>■ When DIP switch 8 is ON, it is not necessary to check the settings using the DIP switch.</p>
6	Sets R7D-SV4 range.	<p>If DRT2-AD04 range is set to the DIP switch and all channels are set to the same range, use the DIP switch to set R7D-SV4/YV2 range. For details on how to set the DIP switch, refer to "4. Switching."</p> <p>If DRT2-AD04/DA02 range setting is not the same as the Configurator setting or all channels, set R7D-SV4/YV2 range using the PC Configurator software. For details on how to set the PC Configurator software, refer to "4 Setting by PC configuration software".</p>
7	Sets the node address.	Set the node address of R7D-SV4 to the same node address as DRT2-AD04 (address 1 in this case).
8	Setting the Baud Rate	 <p>Set the rotary switch to 3 to 9: Automatic follow-up.</p>

9	Removes a DRT2-AD04 from the scan list.	 <p>The screenshot shows the CX-Integrator software interface. The title bar reads "NewProject - CX-Integrator - [Network1(DeviceNet);Net(001)]". The menu bar includes File, Edit, View, Insert, Network, Component, Tools, Windows, and Help. The main workspace displays a network diagram with three components: #00 (CJ1W-DRM21), #02 (DRT2-ID08), and #03 (DRT2-OD08). A tree view on the left shows the project structure: NewProject > DeviceNet > Network 1(DeviceNet). The status bar at the bottom indicates "Ready" and "Off-line".</p>
10	Select R7D-SV4 EDS-file.	 <p>The screenshot shows the "Wizard - Network/Component Settings" dialog box. On the left is the Integrator logo. The "Component" section contains a tree view with "Component Type" expanded to "EDS(DeviceNet)". Under "EDS(DeviceNet)", the "Vendor" is "M-SYSTEM Co., Ltd.", and the "Generic Device" is "R7D-SV4". The "DeviceType" is "AC Drive Device".</p>
11	Register with node address "1".	 <p>The screenshot shows the "Node Address Setup" dialog box. The "Node Address" field contains the value "1". There are "OK" and "Cancel" buttons at the bottom.</p>


12 Select the master I/O assignment (IN) from the device parameter edit of the master.




13 To R7D-SV4 allocation channel Changed to 3310



14 Write the scan list to the master.



15	Connect the unit.	After changing the wiring to the terminal of R7D-SV4/YV2/YS2, connect DeviceNet circuit to the communication connector of DevicNet.
16	Turn on the power.	<p data-bbox="502 174 1212 212">Check that MS and NS of R7D-SV4/YV2/YS2 are lit in green.</p>  <p>The diagram shows a control panel with four components: two indicator lights labeled 'MS' and 'NS' which are circled in red, and three rotary switches. The first switch is labeled 'X10' and 'NODE ADD.', the second is labeled 'X1', and the third is labeled 'B.RATE'. Each rotary switch has a circular dial with numbers 0 through 9.</p>

6 Terminology and definitions

Term	Explanation and define
Remote I/O Communication	<p>This is communication that always shares data between CPU module and slaves.</p> <p>Communication starts automatically by turning on the power supply (communication power supply to the slave and power supply of PLC main unit) and data sharing starts between I/O memory area of CPU unit and the slave unit.</p> <p>The ladder program can only be used to read and write data from and to the area where data is always shared (slave assignment area). However, in this case, the slave is read from or written to the slave on the condition that the slave is operating normally.</p>
Messaging	<p>Message communication is a function to control data transmission/reception (time information, error history, etc.) and special information reading/writing (forced set/reset, etc.) when required (when conditions are met) between nodes on DeviceNet network (between PLC ← master and PLC ← slave).</p> <p>The messaging function has two functions: FINS messaging function and Explicit messaging function.</p>
Master unit	<p>Manages the network and exchanges I/O between PLC and the slave modules.</p> <p>There is only one master unit in the entire network. The master unit must be connected to the end of the trunk line.</p>
Slave module	<p>Outputs OUT data received from the master unit through the network. In addition, the input IN data is sent to the master unit via the network.</p>

7 Reference information

Company	Man.No.	Type	Manual name
OMRON	W380	Model CJ1W-DRM21 Model CS1W-DRM21 (-V1)	DeviceNet Units Operation Manual
OMRON	W404	Model DRT2-AD04 Model DRT2-DA02	DRT2 Series DeviceNet Slave Operation Manual
OMRON	W446	Model WS02-CXPC □-V8	SYSMAC CX-Programmer Operation Manual
OMRON	W464	Model CXONE-AL□□C- V3/AL□□D-V3	SYSMAC CX-Integrator Operation Manual
MG	EN-7802- A	Type R7D-SV4	User's Manual Remote I/O R7 Series Isolated 4-point DC voltage/current input module for DeviceNet
MG	EN-7802- D	Model R7D-YV2	User's Manual Remote I/O R7 Series Insulation 2-point DC voltage-output unit for DeviceNet
MG	ES-7802	Model R7D-YS2	User's Manual Remote I/O R7 Series Insulation 2-point DC current output unit for DeviceNet
MG	EN-9269	Model R7CON	Remote I/O converter R7 Series PC Configurator Software R7 CON User's Manual

8 Notes

- (1) When constructing a system based on this document, please read the instruction manual of the product to be constructed and confirm the specs, performance and safety.

The symbols used in this document have the following meanings:



Safety Key Points

Indicates what should be done or avoided in order to use the product safely.



Usage Notes

Indicates that the product should be implemented or avoided to prevent inoperability, malfunction, or negative impact on performance or functionality.



See Also

Items that you want to read as necessary.

This chapter provides useful information that you should be aware of, as well as reference information for use.

9 Revision History

Revision code	Date of revision	Revision Reason/Revision Page
01	December 15th 2021	First edition
02	May 8th 2025	Change of company name (M-SYSTEM CO., LTD. → MG CO., LTD.)

Note: Do not use this document to operate the Unit.

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN

Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp
The Netherlands

Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra
Technopark, Singapore 119968

Tel: (65) 6835-3011 Fax: (65) 6835-3011

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200
Hoffman Estates, IL 60169 U.S.A.

Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 221 I, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China

Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388

Authorized Distributor:

©OMRON Corporation : 2021-2025 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. P155-EI-02 0525 (1221)