OMRON

Model **FLV-DR**

Direct Ring Lighting

INSTRUCTION SHEET

Thank you for selecting OMRON product. This sheet primarily describes precautions required in installing and operating the product.

Before operating the product, read the sheet thoroughly to acquire sufficient knowledge of the product. For your convenience, keep the sheet at your disposal.

TRACEABILITY INFORMATION:

Omron Europe B.V. Wegalaan 67-69 2132 JD Hoofddorn

Manufacturer Omron Corporation, Shiokoji Horikawa, Shimogyo-ku, Kvoto 600-8530 JAPAN

The following notice applies only to products that carry the CE mark:

This is a class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference

© OMRON Corporation 2013 All Rights Reserved.

PRECAUTIONS ON SAFETY

Meanings of Signal Words



Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

Alert Statements in This Sheet

⚠ WARNING

This product is not designed or rated for ensuring safety of persons either directly or indirectly. Do not use it for such purposes.



Do not disassemble the product. Doing so may cause electric shock due to the high voltage portion. Burn also may result due to high temperature. Do not attempt to disassemble, deform by pressure, incinerate, repair, or modify this product.



Looking into the LED light continuously may cause visual impairment. Do not look directly into the LED light.



⚠ CAUTION

Do not use it exceeding the rated voltage There is a possibility of failure and fire.



Do not connect amplifier units to AC power supply. Risk of explosion.

Beware of danger of burns.

Do not touch the case while the Lighting is ON or immediately after the power is turned OFF, since it is extremely hot.



PRECAUTIONS FOR SAFE USE

Please observe the following precautions for safe use of the products.

- 1 Installation Environment
- · Do not use the product in environments where it can be exposed to inflammable/explosive gas.
- To secure the safety of operation and maintenance, do not install the product close to high-voltage devices and power devices.
- Tighten the screws with the specified torque in this document
- 2. Power Supply and Wiring
- 2. Fower Supply and wiring of the Supply and wiring refer to PRECAUTIONS FOR SAFE USE on the INSTRUCTION SHEET of the dedicated controller (FLV-TCC4\(\sqrt{L}\)/-TCC1\(\sqrt{L}\)/-TCC3HB\(\sqrt{L}\), FLV-ATC\(\sqrt{1024}\sqrt{L}\)).
- . When connecting or disconnecting the lighting connector, be sure to turn off the power of the unit. Not doing so may result in malfunction.
- The temperature may reach 70°C while power is being supplied under thermally neutral environment. Do not touch the product directly. Be sure to wear heat-resistant gloves.
- · High-Voltage lines and power lines must be wired separately from this product. Wiring them together or placing them in the same duct may cause induction, resulting in malfunction or damage.
- · Take sufficient safety measures such as fail-safe circuit to use the product.
- . Do not use in safety circuits for atomic energy or that are critical for human life. • Do not attempt to disassemble, deform by pressure, incinerate, repair, or
- · When disposing of the product, treat as industrial waste
- Be sure to connect a dedicated lighting controller (FLV-TCC4□/-TCC1□ /-TCC3HB , FLV-ATC 1024-). Use of other devices may result in fire, explosion, malfunction or failure.
- If you notice an abnormal condition such as a strange odor, extreme heating of the unit, or smoke, immediately stop using the product, turn off the power, and consult your dealer.
- · Do not drop or impose excessive vibration or shock on the product. It may cause breakdown of the product.
- Ensure that all components which have locking mechanisms are locked before using the product.
- Make sure not to drop the product when unpacking or moving it.
- 4. Applicable standards
- This lighting complied with the EN standard (EN61326) (Electromagnetic environment : Industrial electromagnetic environment (EN/IEC 61326-1 Table 2))
- Also, the following condition is applied to the immunity test of this product. There are case that Lighting brightness fluctuate Max 10%

PRECAUTIONS FOR CORRECT USE

Observe the following to prevent failure, malfunctioning, and adverse effects on performance and the device.

1. Installation site

- Do not install in the following locations:
- Locations where the ambient temperature exceeds the rated temperature range. Locations subject to sudden temperature changes (where condensation will form).
- Locations where the relative humidity is below or above 35 to 85% RH.
- Locations where there are corrosive or flammable gases.
- Locations where there is dust, salt, or iron powder.
- Locations where the device will be subject to direct vibration or shock.
- Locations where there is strong scattered light (laser light, arc welding light, ultraviolet light, etc.)
- Locations exposed to direct sunlight or next to a heater.
- Locations where there is splashing or spraying of water, oil, or chemicals.
 Locations where there is a strong electrical or magnetic field.

- · Do not install the product close to high-voltage devices and/or power devices in order to secure the safety of operations and maintenance.
- When this product and a cable are attached or removed, be sure to turn OFF the power of the Controller first before operation.
- · Never use paint thinner, benzen, acetone, or kerosene to clean the product. Wipe the contamination with a soft cloth included a small amount of alcohol. 3. Power and cable connections
- When using a commercially available switching regulator, make sure that the Frame ground terminal is grounded.
- If there are surges on your power line, connect a surge absorber as
- appropriate for your conditions of use.

 Before turning on the power after the wiring is completed, verify that the power is correct, that there are no incorrect connections such as a shorted load circuit, and that the load current is suitable. Incorrect wiring may cause damage and failures.
- Use the product with the specified voltage. Applying a voltage or AC voltage that exceed the rating may result in burning or explosion of circuit components.
- For cable extension between the lighting and lighting controller, use an optional
 extension cable (FLV-XC /-XC R) or branch cable (FLV-XC S2). Only one extension cable and branch cable can be used.

 The bending radius at cable wiring must be at least 20 mm
- 4.Warming Up
- After turning on the power supply, allow the controller to stand for at least 30 minutes before use. As the circuits are unstable immediately after power on. brightness may gradually change.
- 5. Lighting electricity
- Lighting electricity for lighting equipment to be connected to the Lighting Controller is limited. Be sure to check the lighting electricity written on the plate of the product, label of the packaging box or this manual to connect a lighting within the specified value. 6. Static Electricity
- LEDs are easily damaged by static electricity. A grounded wrist strap should thus be used when installing or conducting maintenance on the Diffusion Board


Cuacification

Specifications											
Item	Model	FLV-DR3220W	FLV-DR4415W	FLV-DR5030W	FLV-DR6615W	FLV-DR7000W	FLV-DR7030W	FLV-DR9000W	FLV-DR9030W	FLV-DR9215W	FLV-DR12030W
		FLV-DR3220R	FLV-DR4415R	FLV-DR5030R	FLV-DR6615R	FLV-DR7000R	FLV-DR7030R	FLV-DR9000R	FLV-DR9030R	FLV-DR9215R	FLV-DR12030R
		FLV-DR3220B	FLV-DR4415B	FLV-DR5030B	FLV-DR6615B	FLV-DR7000B	FLV-DR7030B	FLV-DR9000B	FLV-DR9030B	FLV-DR9215B	FLV-DR12030B
Applicable Controllers		FLV-TCC4□/-TCC1□/-TCC3HB□, FLV-ATC□1024-□									
Lighting color (peak wavelength)		W:White, R:Red(Typ.635nm), B:Blue(Typ.460nm)									
Light source		LED									
LED Safety		W, B: Risk Group 2 R:Risk Group 1 (IEC62471)									
Electricity	White	1.4W	2.7W	3.1W	5.0W	5.0W	5.0W	8.8W	8.1W	7.4W	11.9W
	Red	1.3W	1.7W	1.8W	3.9W	3.7W	3.7W	7.0W	6.6W	5.4W	9.8W
	Blue	1.4W	2.7W	3.1W	5.0W	5.0W	5.0W	8.8W	8.1W	7.4W	11.9W
Insulation Resistance		20 MΩ (250VDC)									
Ambient Temperature		Operating: 0 to +50°C, Storage: -15 to +60°C (with no icing or condensation)									
Ambient Humidity		Operating and storage: 35% to 85% (with no condensation)									
Degree of Protection		IP20 (IEC60529)									
Vibration Resistance(destructive)		10 to 150 Hz, (0.7mm double amplitude) 80 min. each in X, Y, and Z directions									
Shock Resistance (destructive)		150 m/s ² 3 times each in 6 directions(up/down, left/right, forward/backward)									
Materials		Case: Aluminum									
Weight		Approx.60g Approx.70g Approx.60g Approx.120g Approx.110g Approx.120g Approx.20g Approx.200g Approx.200g Approx.360g									
Accessories		Instruction sheet (this sheet)									

Connection with Lighting Controller

Mounting


Align the positions of "the tab of the connector at the lighting cable" and "protrusion of the lighting connector at the Lighting Controller", and then insert it until it clicks.




Removing

Hold "the tab of the connector at the lighting cable" in the arrow (←) direction and pull it straight.


Do not pull out with excessive force without pressing the tab. Doing so may break the wire.




Dimensions (Unit:mm)




Tightening torque: 0.54N · m



Tightening torque: 0.54N · m




Tightening torque: 0.54N · m




Tightening torque: 0.54N · m

●FLV-DR7000□




Tightening torque: 0.54N · m



●FLV-DR9000□






Tightening torque: 0.54N · m


●FLV-DR9030□







Tightening torque: 0.54N · m

●FLV-DR9215□





Tightening torque: 0.54N · m



Tightening torque: 0.54N · m

Options

Diffuser plate (FLV-DR \square DF) and polarizing plate (FLV-DR \square PL) are available.

Suitability for Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS. AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

See also Product catalog for Warranty and Limitation of Liability.

OMRON Corporation Industrial Automation Company Tokyo, JAPAN Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V. Sensor Business Unit

Carl-Benz-Str. 4, D-71154 Nufringen, Germany Tel: (49) 7032-811-0/Fax: (49) 7032-811-199

MRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark,

Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,

200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

D(S) Oct, 2014